

# **Core16550 v3.0**

*Handbook*

---

## **Actel Corporation, Mountain View, CA 94043**

© 2008 Actel Corporation. All rights reserved.

Printed in the United States of America

Part Number: 50200110-1

Release: January 2008

No part of this document may be copied or reproduced in any form or by any means without prior written consent of Actel.

Actel makes no warranties with respect to this documentation and disclaims any implied warranties of merchantability or fitness for a particular purpose. Information in this document is subject to change without notice. Actel assumes no responsibility for any errors that may appear in this document.

This document contains confidential proprietary information that is not to be disclosed to any unauthorized person without prior written consent of Actel Corporation.

### **Trademarks**

Actel and the Actel logo are registered trademarks of Actel Corporation.

Adobe and Acrobat Reader are registered trademarks of Adobe Systems, Inc.

All other products or brand names mentioned are trademarks or registered trademarks of their respective holders.

---

# Table of Contents

Introduction . . . . .	5
Supported Device Families . . . . .	6
Core Version . . . . .	6
Device Utilization and Performance . . . . .	6
<b>1 Functional Block Description . . . . .</b>	<b>7</b>
Software Interface . . . . .	8
<b>2 Tool Flows . . . . .</b>	<b>17</b>
Licenses . . . . .	17
CoreConsole . . . . .	17
Importing into Libero IDE . . . . .	18
<b>3 Core16550 . . . . .</b>	<b>19</b>
Parameters . . . . .	19
<b>4 Core Interfaces . . . . .</b>	<b>21</b>
I/O Signal Description . . . . .	21
<b>5 Timing Diagrams . . . . .</b>	<b>23</b>
Receiver Synchronization . . . . .	24
<b>6 Testbench Operation . . . . .</b>	<b>25</b>
Verification Testbench . . . . .	25
User Testbench . . . . .	26
<b>A List of Document Changes . . . . .</b>	<b>29</b>
<b>B Product Support . . . . .</b>	<b>31</b>
Customer Service . . . . .	31
Actel Customer Technical Support Center . . . . .	31
Actel Technical Support . . . . .	31
Website . . . . .	31
Contacting the Customer Technical Support Center . . . . .	31
<b>Index . . . . .</b>	<b>33</b>



# Introduction

Core16550 is a standard UART providing software compatibility with the popular 16550 device. It performs serial-to-parallel conversion on data originating from modems or other serial devices, and performs parallel-to-serial conversion on data from a CPU to these devices. When transmitting, the data is written in parallel into the transmit FIFO of the UART. The data is then transmitted in serial form. When receiving data, the UART transforms the serial input data into a parallel form to facilitate reading by the processor. A typical 16550 application is shown in [Figure 1](#).




Figure 1 · Typical 16550 Application

## Supported Device Families

Fusion  
 IGLOO™  
 IGLOOe  
 ProASIC®3L  
 ProASIC3  
 ProASIC3E

## Core Version

This handbook applies to Core16550 v3.0. The release notes provided with the core list known discrepancies between this handbook and the core release associated with the release notes.

## Device Utilization and Performance

Core16550 utilization and performance data are summarized in [Table 1](#).

Table 1 · Core16550 Utilization and Performance

Family	Cell or Tiles			RAM Blocks	Utilization	
	Sequential	Combinatorial	Total		Device	Total
IGLOO™/IGLOOE	237	1,010	1,247	2	AGL600-STD	9%
Fusion	237	1,010	1,247	2	AFS600-STD	9%
ProASIC®3/E	237	1,010	1,247	2	A3P600-STD	9%
ProASIC <sup>PLUS</sup> ®	233	1,209	1,442	2	APA075-STD	47%
RTAX-S	229	608	837	2	RTAX250S-STD	20%
Axcelerator®	229	608	837	2	AX125-STD	42%

*Note:* The above data were obtained by typical synthesis and place-and-route flow.

# Functional Block Description

This section provides a short description for each element of the internal block diagram in [Figure 1-1](#).




Figure 1-1 · Core16550 Block Diagram

## RWControl

The RWControl block is responsible for handling the communications with the processor (parallel) side of the system. All writing and reading of internal registers is accomplished through this block.

## UART\_Reg

The UART\_Reg block holds all of the device internal registers.

## RXBlock

This is the Receiver block. RXBlock receives the incoming serial word. It is programmable to recognize data widths, such as 5, 6, 7, or 8 bits; various parity settings, such as even, odd, or no-parity; and different stop bits, such as 1, 1½, and 2 bits. RXBlock checks for errors in the input data stream, such as overrun errors, frame errors, parity errors, and break errors. If the incoming word has no problems, it is placed in the Receiver FIFO.

## Interrupt Control

The Interrupt Control block sends an interrupt signal back to the processor, depending on the state of the FIFO and its received and transmitted data. The Interrupt Identification Register provides the level of the interrupt. Interrupts are sent for empty transmission/receipt buffers (or FIFOs), an error in receiving a character, or other conditions requiring the attention of the processor.

## Baud Rate Generator

This block takes the input PCLK and divides it by a programmed value (from 1 to  $2^{16} - 1$ ). The result is divided by 16 to create the transmission clock (BAUDOUT).

## TXBlock

The Transmit block handles the transmission of data written to the Transmit FIFO. It adds the required start, parity, and stop bits to the data being transmitted so the receiving device can do the proper error handling and receiving.

## Software Interface

The Core16550 register definitions and address mappings are described in this section. The Core16550 register summary is shown in [Table 1-1](#).

Table 1-1 · Core16550 Register Summary

PADDR[4:0] (Address)	Divisor Latch Access Bit* (DLAB)	Name	Symbol	Default (reset) Value	No. of Bits	Read/Write
00	0	Receiver Buffer Register	RBR	XX	8	R
00	0	Transmitter Holding Register	THR	XX	8	W
00	1	Divisor Latch (LSB)	DLR	01h	8	R/W
04	1	Divisor Latch (MSB)	DMR	00h	8	R/W
04	0	Interrupt Enable Register	IER	00h	8	R/W
08	X	Interrupt Identification Register	IIR	01h	8	R
08	X	FIFO Control Register	FCR	00h	8	W
0C	X	Line Control Register	LCR	00h	8	R/W
10	X	Modem Control Register	MCR	00h	8	R/W
14	X	Line Status Register	LSR	60h	8	R
18	X	Modem Status Register	MSR	00h	8	R
1C	X	Scratch Register	SR	00h	8	R/W

*Note:* \*DLAB is the MSB of the Line Control Register (LCR bit 7).

## Receiver Buffer Register

The Receiver Buffer Register is defined in [Table 1-2](#).

Table 1-2 · Receiver Buffer Register (read only) – Address 0 DLAB 0

Bits	Name	Default State	Valid States	Function
7..0	RBR	XX	0..FFh	Received data bits. Bit 0 is the LSB, and is the first received bit.

## Transmitter Holding Register

The Transmitter Holding Register is defined in [Table 1-3](#).

Table 1-3 · Transmitter Holding Register (write only)

Bits	Name	Default State	Valid States	Function
7..0	THR	XX	0..FFh	Data bits to be transmitted. Bit 0 is the LSB, and is transmitted first.

## FIFO Control Register

The FIFO Control Register is defined in [Table 1-4](#).

Table 1-4 · FIFO Control Register (write only)

Bits (7:0)	Default State	Valid States	Function															
0	0	0, 1	Enables both the TX and RX FIFOs. This bit must be set to 1 when other FCR bits are written to or they will not be programmed. 0 – Disabled 1 – Enabled															
1	0	0, 1	Clears all bytes in the RX FIFO and resets its counter logic. The shift register is not cleared. 0 – Disabled 1 – Enabled															
2	0	0, 1	Clears all bytes in the TX FIFO and resets its counter logic. The shift register is not cleared. 0 – Disabled 1 – Enabled															
3	0	0, 1	Enables RXRDYN and TXRDYN pins when set to 1. Otherwise, they are disabled.															
4, 5	0	0, 1	Reserved for future use.															
6, 7	0	0, 1	These bits are used to set the trigger level for the RX FIFO interrupt. <table border="0" style="margin-left: 20px;"> <tr> <td>7</td> <td>6</td> <td>RX FIFO Trigger Level (bytes)</td> </tr> <tr> <td>0</td> <td>0</td> <td>01</td> </tr> <tr> <td>0</td> <td>1</td> <td>04</td> </tr> <tr> <td>1</td> <td>0</td> <td>08</td> </tr> <tr> <td>1</td> <td>1</td> <td>14</td> </tr> </table>	7	6	RX FIFO Trigger Level (bytes)	0	0	01	0	1	04	1	0	08	1	1	14
7	6	RX FIFO Trigger Level (bytes)																
0	0	01																
0	1	04																
1	0	08																
1	1	14																

## The Divisor Control Registers

The baud rate (BR) clock is generated by dividing the input reference clock (PCLK) by 16 and the Divisor value. The exact formula is shown in EQ1-1:

$$BR = \frac{PCLK}{16 \cdot \text{DivisorValue}}$$

EQ 1-1

Table 1-5 gives an example of divisor values for desired baud rates when using an 18.432 MHz reference clock.

Table 1-5 · Divisor Latch (LS), (MS)

Bits	Name	Default State	Valid States	Function
7..0	DLR	01h	01..FFh	The LSB of Divisor value
7..0	DMR	00h	00..FFh	The MSB of Divisor value

Table 1-6 · Baud Rates and Divisor Values for 18.432 MHz Reference Clock

Baud Rate	Decimal Divisor (Divisor Value)	Percent Error
50	23,040	0.0000%
75	15,360	0.0000%
110	10,473	-0.2865%
134.5	8,565	0.0876%
150	7,680	0.0000%
300	3,840	0.0000%
600	1,920	0.0000%
1,200	920	4.3478%
1,800	640	0.0000%
2,000	576	0.0000%
2,400	480	0.0000%
3,600	320	0.0000%
4,800	240	0.0000%
7,200	160	0.0000%
9,600	120	0.0000%
19,200	60	0.0000%
38,400	30	0.0000%
56,000	21	-2.0408%

## Interrupt Enable Register

The Interrupt Enable Register is defined in [Table 1-7](#).

Table 1-7 · Interrupt Enable Register

Bits	Name	Default State	Valid State	Function
0	ERBFI	0	0, 1	Enables Received Data Available Interrupt 0 – Disabled 1 – Enabled
1	ETBEI	0	0, 1	Enables the Transmitter Holding Register Empty Interrupt 0 – Disabled 1 – Enabled
2	ELSI	0	0, 1	Enables the Receiver Line Status Interrupt 0 – Disabled 1 – Enabled
3	EDSSI	0	0, 1	Enables the Modem Status Interrupt 0 – Disabled 1 – Enabled
7..4	Reserved	0	0	Always 0

## Interrupt Identification Register

The Interrupt Identification Register is defined in [Table 1-8](#).

Table 1-8 · Interrupt Identification Register

Bits	Name	Default State	Valid States	Function
3..0	IIR	1h	0..Ch	Interrupt Identification bits. Described in <a href="#">Table 1-9</a> .
5..4	Reserved	00	00	Always 00
7..6	Mode	11	11	11 – FIFO mode

The Interrupt Identification Register field is defined in [Table 1-9](#).

Table 1-9 · Interrupt Identification Register Field (IIR)

IIR Value[3:0]	Priority Level	Interrupt Type	Interrupt Source	Interrupt Reset Control
0110	Highest	Receiver Line Status	Overrun error, parity error, framing error, or break interrupt	Reading the Line Status Register
0100	Second	Received Data Available	Receiver Data Available	Reading the Receiver Buffer Register or the FIFO drops below the trigger level
1100	Second	Character Timeout Indication	No characters have been read from the RX FIFO during the last four character times and there was at least one character in it during this time.	Reading the Receiver Buffer Register
0010	Third	Transmitter Holding Register Empty	Transmitter Holding Register Empty	Reading the IIR or writing into the Transmitter Holding Register
0000	Fourth	Modem Status	Clear to Send, Data Set Ready, Ring Indicator, or Data Carrier Detect	Reading the modern Status Register

## Line Control Register

The Line Control Register is defined in [Table 1-10](#).

Table 1-10 · Line Control Register

Bits	Name	Default State	Valid States	Function
1..0	WLS	0	0..3h	Word Length Select 00 – 5 bits 01 – 6 bits 10 – 7 bits 11 – 8 bits
2	STB	0	0, 1	Number of Stop Bits 0 – 1 stop bit 1 – 1½ stop bits when WLS = 00 2 stop bits in other cases
3	PEN	0	0, 1	Parity Enable 0 – Disabled 1 – Enabled. Parity is added in transmission and checked in receiving.
4	EPS	0	0, 1	Even Parity Select 0 – Odd parity 1 – Even parity
5	SP	0	0, 1	Stick Parity 0 – Disabled 1 – Enabled When stick parity is enabled, it works as follows: Bits 4..3 11 – 0 will be sent as a parity bit, and checked in receiving. 01 – 1 will be sent as a parity bit, and checked in receiving.
6	SB	0	0, 1	Set Break 0 – Disabled 1 – Set break. SOUT is forced to 0. This does not have any effect on transmitter logic. The break is disabled by setting the bit to 0.
7	DLAB	0	0, 1	Divisor Latch Access Bit 0 – Disabled. Normal addressing mode in use 1 – Enabled. Enables access to the Divisor Latch registers during read or write operation to addresses 0 and 1.

## Modem Control Register

The Modem Control Register is defined in [Table 1-11](#).

Table 1-11 · Modem Control Register

Bits	Name	Default State	Valid States	Function
0	DTR	0	0, 1	Controls the Data Terminal Ready (DTR <sub>n</sub> ) output. 0 – DTR <sub>n</sub> <= 1 1 – DTR <sub>n</sub> <= 0
1	RTS	0	0, 1	Controls the Request to Send (RTS <sub>n</sub> ) output. 0 – RTS <sub>n</sub> <= 1 1 – RTS <sub>n</sub> <= 0
2	Out1	0	0, 1	Controls the Output1 (OUT1 <sub>n</sub> ) signal. 0 – OUT1 <sub>n</sub> <= 1 1 – OUT1 <sub>n</sub> <= 0
3	Out2	0	0, 1	Controls the Output2 (OUT2 <sub>n</sub> ) signal. 0 – OUT2 <sub>n</sub> <= 1 1 – OUT2 <sub>n</sub> <= 0
4	Loop	0	0, 1	Loop enable bit 0 – Disabled 1 – Enabled. The following happens in loop mode: SOUT is set to 1. The SIN, DSR <sub>n</sub> , CTS <sub>n</sub> , RI <sub>n</sub> , and DCD <sub>n</sub> inputs are disconnected. The output of the Transmitter Shift Register is looped back into the Receiver Shift Register. The modem control outputs (DTR <sub>n</sub> , RTS <sub>n</sub> , OUT1 <sub>n</sub> , and OUT2 <sub>n</sub> ) are connected internally to the modem control inputs, and the modem control output pins are set at 1. In loopback mode, the transmitted data is immediately received, allowing the CPU to check the operation of the UART. The interrupts are operating in loop mode.
7..4	Reserved	0h	0	Reserved

## Line Status Register

The Line Status Register is defined in [Table 1-12](#).

Table 1-12 · Line Status Register (read only)

Bits	Name	Default State	Valid States	Function
0	DR	0	0, 1	Data Ready indicator 1 when a data byte has been received and stored in the receive buffer or the FIFO. DR is cleared to 0 when the CPU reads the data from the receive buffer or the FIFO.
1	OE	0	0, 1	Overrun Error indicator Indicates that the new byte was received before the CPU read the byte from the receive buffer, and that the earlier data byte was destroyed. OE is cleared when the CPU reads the Line Status Register. If the data continues to fill the FIFO beyond the trigger level, an overrun error will occur once the FIFO is full and the next character has been completely received in the shift register. The character in the shift register is overwritten, but it is not transferred to the FIFO.
2	PE	0	0, 1	Parity Error indicator Indicates that the received byte had a parity error. PE is cleared when the CPU reads the Line Status Register. This error is revealed to the CPU when its associated character is at the top of the FIFO.
3	FE	0	0, 1	Framing Error indicator Indicates that the received byte did not have a valid Stop bit. FE is cleared when the CPU reads the Line Status Register. The UART will try to resynchronize after a framing error. To do this, it assumes that the framing error was due to the next start bit, so it samples this start bit twice, and then starts receiving the data. This error is revealed to the CPU when its associated character is at the top of the FIFO.
4	BI	0	0, 1	Break Interrupt indicator Indicates that the received data is at 0 longer than a full word transmission time (start bit + data bits + parity + stop bits). BI is cleared when the CPU reads the Line Status Register. This error is revealed to the CPU when its associated character is at the top of the FIFO. When break occurs, only one zero character is loaded into the FIFO.
5	THRE	1	0, 1	Transmitter Holding Register Empty indicator Indicates that the UART is ready to transmit a new data byte. THRE causes an interrupt to the CPU when bit 1 (ETBEI) in the Interrupt Enable Register is 1. This bit is set when the TX FIFO is empty. It is cleared when at least one byte is written to the TX FIFO.
6	TEMT	1	0, 1	Transmitter Empty indicator This bit is set to 1 when both the transmitter FIFO and shift registers are empty.
7	FIER	0	1	This bit is set when there is at least one parity error, framing error, or break indication in the FIFO. FIER is cleared when the CPU reads the LSR if there are no subsequent errors in the FIFO.

## Modem Status Register

The Modem Status Register is defined in [Table 1-13](#).

Table 1-13 · Modem Status Register (read only)

Bits	Name	Default State	Valid States	Function
0	DCTS	0	0, 1	Delta Clear to Send indicator. Indicates that the CTSn input has changed state since the last time it was read by the CPU.
1	DDSR	0	0, 1	Delta Data Set Ready indicator Indicates that the DSRn input has changed state since the last time it was read by the CPU.
2	TERI	0	0, 1	Trailing Edge of Ring Indicator detector. Indicates that RI input has changed from 0 to 1.
3	DDCD	0	0, 1	Delta Data Carrier Detect indicator Indicates that DCD input has changed state. NOTE: Whenever bit 0, 1, 2, or 3 is set to 1, a Modem Status Interrupt is generated.
4	CTS	0	0, 1	Clear to Send The complement of the CTSn input. When bit 4 of the Modem Control Register (MCR) is set to 1 (loop), this bit is equivalent to DTR in the MCR.
5	DSR	0	0, 1	Data Set Ready The complement of the DSR input. When bit 4 of the MCR is set to 1 (loop), this bit is equivalent to RTSn in the MCR.
6	RI	0	0, 1	Ring Indicator The complement of the RIn input. When bit 4 of the MCR is set to 1 (loop), this bit is equivalent to OUT1 in the MCR.
7	DCD	0	0, 1	Data Carrier Detect The complement of DCDn input. When bit 4 of the MCR is set to 1 (loop), this bit is equivalent to OUT2 in the MCR.

## Scratch Register

The Scratch Register is defined in [Table 1-14](#).

Table 1-14 · Scratch Register

Bits	Name	Default State	Function
7..0	SCR	00h	Read/write register for CPU. No effects on UART operation.



## Tool Flows

### Licenses

Core16550 is licensed in three ways. Depending on your license, tool flow functionality may be limited.

### Evaluation

Pre-compiled simulation libraries are provided, allowing the core to be instantiated in CoreConsole and simulated within Actel Libero® Integrated Design Environment (IDE), as described in the “CoreConsole” section. Using the Evaluation version of the core, it is possible to create and simulate the complete design in which the core is being included. The design cannot be synthesized, as source code is not provided.

### Obfuscated

Complete RTL code is provided for the core, enabling the core to be instantiated with CoreConsole. Simulation, Synthesis, and Layout can be performed with Actel Libero IDE. The RTL code for the core is obfuscated, and some of the testbench source files are not provided. They are pre-compiled into the compiled simulation library instead.

### RTL

Complete RTL source code is provided for the core and testbenches.

## CoreConsole

Core16550 is preinstalled in the CoreConsole IP Deployment Platform (IDP). To use the core, click and drag it from the IP core list into the main window. The CoreConsole project can be exported to Actel Libero IDE at this point, providing access to the core only. Alternatively, IP blocks can be interconnected, allowing the complete system to be exported from CoreConsole to Libero IDE. The core can be configured using the configuration GUI within CoreConsole, as shown in Figure 2-1.




Figure 2-1 · Core16550 Configuration within CoreConsole

After configuring the core, Actel recommends that you use the top-level Auto Stitch function to connect all the core interface signals to the top level of the CoreConsole project.

Once the core is configured, invoke the **Generate** function in CoreConsole. This will export all the required files to the project directory in the *LiberoExport* directory. This is in the CoreConsole installation directory by default.

## Importing into Libero IDE

After generating and exporting the core from CoreConsole, the core can be imported into Actel Libero IDE. Create a new project in Libero IDE and import the CoreConsole project from the *LiberoExport* directory. Libero IDE will then install the core and the selected testbenches, along with constraints and documentation, into its project.

**Note:** If two or more DirectCores are required, they can both be included in the same CoreConsole project and imported into Libero IDE at the same time.

## Simulation Flows

To run simulations, select the required testbench flow within CoreConsole and run **Save & Generate** from the Generate pane. Select the required testbench through the core configuration GUI in CoreConsole. The following simulation environments are supported:

- Full Core16550 verification environment (Verilog only)
- Simple testbench (VHDL and Verilog)

When CoreConsole generates the Libero IDE project, it will install the appropriate testbench files. To run the testbenches, **simply set the design root to the Core16550 instantiation in the Actel Libero IDE file manager** and click the **Simulation** icon in Libero IDE. This will invoke ModelSim® and automatically run the simulation.

## Synthesis in Libero IDE

To run Synthesis on the core with parameters set in CoreConsole, set the design root to the top of the project imported from CoreConsole. This is a wrapper around the core that sets all the generics appropriately. Make sure the required timing constraints files are associated with the synthesis tool.

Click the **Synthesis** icon in Libero IDE. The synthesis window appears, displaying the Synplicity® project. To run Synthesis, click the **Run** icon.

## Place-and-Route in Libero IDE

Having set the design route appropriately and run Synthesis, click the **Layout** icon in Libero IDE to invoke Designer. Core16550 requires no special place-and-route settings.

---

## Core16550

### Parameters

Core16550 has a top-level parameter/generic that is used to select the device family ([Table 3-1](#)).

Table 3-1 · Core Parameters

Parameter Name	Description	Allowed Values	Default
FAMILY	Must be set to match the supported FPGA family. 11 – Axcelerator 12 – RTAX-S 14 – ProASIC <sup>PLUS</sup> 15 – ProASIC3 16 – ProASIC3E 17 – Fusion 20 – IGLOO 21 – IGLOOe	11 to 21	15



## Core Interfaces

### I/O Signal Description

Core16550 I/O definitions are given in [Table 4-1](#).

Table 4-1 · I/O Signal Summary

Name	Type	Polarity	Description
PRESETN	In	LOW	Master reset
PCLK	In	-	Master clock PCLK is divided by the value of the Divisor Registers. The result is then divided again by 16 to produce the baud rate. The resultant signal is the BAUDOUT signal. The rising edge of this pin is used to strobe all input and output signals.
PWRITE	In	HIGH	APB write/read enable, active high When HIGH, data is written to the specified address location. When LOW, data is read from the specified address location.
PADDR[4:0]	In		APB Address This bus provides the link for the CPU to the address of the register of Core16550 to be read from or written to.
PSEL	In	HIGH	APB select When this is HIGH along with PENABLE, reading and writing to Core16550 is enabled.
PWDATA[7:0]	In	-	Data input bus Data on this bus will be written into the addressed register during a write cycle.
PENABLE	In	HIGH	APB enable When this is HIGH along with PSEL, reading and writing to Core16550 is enabled.
PRDATA[7:0]	Out	-	Data output bus This bus will hold the value of the addressed register during a read cycle.
CTS <sub>n</sub>	In	LOW	Clear to Send This active low signal is an input showing when the attached device (modem) is ready to accept data. Core16550 passes this information to the CPU via the Modem Status register. This register also indicates if the CTS <sub>n</sub> signal has changed since the last time the register was read.
DSR <sub>n</sub>	In	LOW	Data Set Ready This active low signal is an input indicating when the attached device (modem) is ready to set up a link with Core16550. Core16550 passes this information to the CPU via the Modem Status Register. This register also indicates if the DSR <sub>n</sub> signal has changed since the last time the register was read.
DCD <sub>n</sub>	In	LOW	Data Carrier Detect This active low signal is an input indicating when the attached device (modem) has detected a carrier. Core16550 passes this information to the CPU via the Modem Status Register. This register also indicates if the DCD <sub>n</sub> signal has changed since the last time the register was read.
SIN	In	-	Serial Input Data This is the data that will be transmitted into Core16550. It is synchronized with the PCLK input pin.

Table 4-1 · I/O Signal Summary (continued)

Name	Type	Polarity	Description
RIn	In	LOW	Ring Indicator This active low signal is an input showing when the attached device (modem) has sensed a ring signal on the telephone line. Core16550 passes this information to the CPU via the Modem Status Register. This register also indicates when the RIn trailing edge was sensed.
SOUT	Out	–	Serial output data This is the data that will be transmitted from Core16550. It is synchronized with the BAUDOUT output pin.
RTSn	Out	LOW	Request to Send This active low output signal is used to inform the attached device (modem) that Core16550 is ready to send data. It is programmed by the CPU via the Modem Control Register.
DTRn	Out	LOW	Data Terminal Ready This active low output signal informs the attached device (modem) that Core16550 is ready to establish a communications link. It is programmed by the CPU via the Modem Control Register.
OUT1n	Out	LOW	Output 1 This active low output is a user-defined signal. It is programmed by the CPU via the Modem Control Register and is set to the opposite value. programmed.
OUT2n	Out	LOW	Output 2 This active low output signal is a user-defined signal. It is programmed by the CPU via the Modem Control Register and is set to the opposite value. programmed.
INTR	Out	HIGH	Interrupt Pending This active high output signal is the interrupt output signal from Core16550. It can be programmed to become active on certain events, informing the CPU that such an event has occurred (see “ <a href="#">Interrupt Identification Register</a> ” on page 11 for details). The CPU can then take appropriate action.
BAUDOUTn	Out	LOW	Baud out This is an output clock signal derived from the input clock (see PCLK description) for synchronizing the data output stream from SOUT.
RXRDN	Out	LOW	Receiver ready to receive transmissions This active low output signal indicates to the CPU that the receiver section of Core16550 is available for data to be read.
TXRDN	Out	LOW	Transmitter ready to transmit data This active low signal indicates to the CPU that the transmitter section of Core16550 has space to write data for transmission.
rxfifo_empty	Out	High	Receive FIFO empty This signal goes HIGH when the receive FIFO is empty.
rxfifo_full	Out	High	Receive FIFO full This signal goes HIGH when the receive FIFO is full.

## Timing Diagrams

Figure 5-1 and Figure 5-2 depict write cycle and read cycle timing relationships relative to the APB system clock, PCLK.

### Register Write

As shown in Figure 5-1, the Address, Select, and Enable signals are latched and must be valid prior to the rising edge of PCLK. Writing occurs at the rising edge of the PCLK signal.




Figure 5-1 · Data Write Cycle

### Register Read

As shown in Figure 5-2, the Address, Select, and Enable signals are latched and must be valid prior to the rising edge of PCLK. Reading occurs at the rising edge of the PCLK signal.




Figure 5-2 · Data Read Cycle

More detailed descriptions and timing waveforms can be found in the AMBA specification: [http://www.amba.com/products/solutions/AMBA\\_Spec.html](http://www.amba.com/products/solutions/AMBA_Spec.html).

## Receiver Synchronization

When the Receiver detects a LOW state in the incoming data stream, it will synchronize to it. After the start edge, the UART will wait  $1.5 \times$  (the normal bit length). This causes each subsequent bit to be read at the middle of its width.

Figure 5-3 depicts this synchronization process.




Figure 5-3 · Receiver Synchronization

## Testbench Operation

Three testbenches are provided with Core16550:

- Verilog verification testbench: Complex testbench that verifies core operation. This testbench exercises all the features of the core. Actel recommends not modifying this testbench. This Verilog testbench can be used to simulate the VHDL version of the core if a mixed-mode simulator is available.
- VHDL user testbench: Simple-to-use testbench written in VHDL. This testbench is intended for customer modification.
- Verilog user testbench: Simple-to-use testbench written in Verilog. This testbench is intended for customer modification.

### Verification Testbench

Included with the releases of Core16550 is a verification testbench that verifies operation of the Core16550 macro. A simplified block diagram of the verification testbench is shown in [Figure 6-1](#).

#### Verification Testbench Overview

A procedural testbench controls the behavioral microcontroller and simulated connection to apply the sequential stimuli to Core16550 in the testbench shown in [Figure 6-1](#). The behavioral microcontroller emulates host CPU access to Core16550 via a set of Verilog tasks. The simulated connection loops the output SOUT (serial output) to the input SIN (serial input) of Core16550 to simulate normal operation, and may alter the loopback values to simulate abnormal conditions, such as error conditions.




Figure 6-1 · Core16550 Verification Testbench

## Verification Testbench Tests

The verification test suite for Core16550 consists of the tests listed in [Table 6-1](#).

Table 6-1 · Core16550 Verification Tests

Test Name	Description
Core16550tb1	Registers' reset values, writing, and reading Transmit FIFO and Receive FIFO THRE and TEMT bits of the LSR register
Core16550tb2	Line Status Register (LSR) bits DR, OE, PE, FE, BI, and LSR7 FIFO Control Register (FCR) bit FCR1 Interrupt Identification Register (IIR): Receiver Line Status Receiver Data Available and THR Empty (THRE) Interrupt Enable Register (IER): Receiver Line Status interrupt enable Receiver Data Available interrupt enable, THR Empty (THRE) and interrupt enable
Core16550tb3	Interrupt Identification Register (IIR) Interrupt Enable Register (IER)
Core16550tb4	General Transmission and Receiving Primary outputs DTRn, RTSn, OUT1n, and OUT2n Primary inputs and their effects on the Modem Status Register (MSR) Bits CTSn, DSRn, DCDn, SIN and Interrupts
Core16550tb5	Baud Rate Test
Core16550tb6	Line Status Register (LSR) bits OE, PE, FE, and BI Interrupt Identification Register (IIR) Interrupt Enable Register (IER)
Core16550tb7	Miscellaneous Tests

## User Testbench

A block diagram of the example user design and testbench is shown in [Figure 6-2](#).




Figure 6-2 · Core16550 User Testbench

The user testbench includes a simple example design that serves as a reference for users who want to implement their own designs.

The testbench for the example user design implements a subset of the functionality tested in the verification testbench, described in “[Verification Testbench](#)” on page 25. Conceptually, as shown in [Figure 6-2](#) on page 26, instantiation of Core16550 is simulated using a behavioral microcontroller and a simulated loopback connection. Example transmit and receive by the same Core16550 unit are demonstrated by the user testbench so you can gain a basic understanding of how to use this core.

The user testbench demonstrates the basic setup, transmit, and receive operations of Core16550. The user testbench exercises the following:

1. Write to the control registers.
2. Read the control registers.
3. Turn on transmit and receive.
4. Transmit and receive one byte.
5. Check received data.



---

## List of Document Changes

The following table lists critical changes that were made in the current version of the document.

Previous Version	Changes in Current Version (v2.1)	Page
v2.0	The <a href="#">“Supported Device Families”</a> section on page 6 was added.	6



---

## Product Support

Actel backs its products with various support services including Customer Service, a Customer Technical Support Center, a web site, an FTP site, electronic mail, and worldwide sales offices. This appendix contains information about contacting Actel and using these support services.

### Customer Service

Contact Customer Service for non-technical product support, such as product pricing, product upgrades, update information, order status, and authorization.

From Northeast and North Central U.S.A., call 650.318.4480

From Southeast and Southwest U.S.A., call 650.318.4480

From South Central U.S.A., call 650.318.4434

From Northwest U.S.A., call 650.318.4434

From Canada, call 650.318.4480

From Europe, call 650.318.4252 or +44 (0) 1276 401 500

From Japan, call 650.318.4743

From the rest of the world, call 650.318.4743

Fax, from anywhere in the world 650.318.8044

### Actel Customer Technical Support Center

Actel staffs its Customer Technical Support Center with highly skilled engineers who can help answer your hardware, software, and design questions. The Customer Technical Support Center spends a great deal of time creating application notes and answers to FAQs. So, before you contact us, please visit our online resources. It is very likely we have already answered your questions.

### Actel Technical Support

Visit the [Actel Customer Support website \(www.actel.com/custsup/search.html\)](http://www.actel.com/custsup/search.html) for more information and support. Many answers available on the searchable web resource include diagrams, illustrations, and links to other resources on the Actel web site.

### Website

You can browse a variety of technical and non-technical information on Actel's [home page](http://www.actel.com), at [www.actel.com](http://www.actel.com).

### Contacting the Customer Technical Support Center

Highly skilled engineers staff the Technical Support Center from 7:00 A.M. to 6:00 P.M., Pacific Time, Monday through Friday. Several ways of contacting the Center follow:

#### Email

You can communicate your technical questions to our email address and receive answers back by email, fax, or phone. Also, if you have design problems, you can email your design files to receive assistance. We constantly monitor the email account throughout the day. When sending your request to us, please be sure to include your full name, company name, and your contact information for efficient processing of your request.

The technical support email address is [tech@actel.com](mailto:tech@actel.com).

## Phone

Our Technical Support Center answers all calls. The center retrieves information, such as your name, company name, phone number and your question, and then issues a case number. The Center then forwards the information to a queue where the first available application engineer receives the data and returns your call. The phone hours are from 7:00 A.M. to 6:00 P.M., Pacific Time, Monday through Friday. The Technical Support numbers are:

**650.318.4460**

**800.262.1060**

Customers needing assistance outside the US time zones can either contact technical support via email ([tech@actel.com](mailto:tech@actel.com)) or contact a local sales office. [Sales office listings](#) can be found at [www.actel.com/contact/offices/index.html](http://www.actel.com/contact/offices/index.html).



---

# Index

## A

Actel  
  electronic mail 31  
  telephone 32  
  web-based technical support 31  
  website 31

## B

baud rate generator 8  
blocks  
  Baudrate Generator 8  
  Interrupt Control 7  
  RWControl 7  
  RXBlock 7  
  Transmit 8  
  UART\_Reg 7

## C

contacting Actel  
  customer service 31  
  electronic mail 31  
  telephone 32  
  web-based technical support 31  
core  
  interfaces 21  
  version 6  
Core16550  
  typical application 5  
  version 6  
CoreConsole 17  
customer service 31

## D

description 5  
device utilization and performance 6  
Divisor Control Registers 10

## F

FIFO Control Register 9  
functional block description 7

## G

generics 19

## I

I/O signal descriptions 21  
importing into Libero IDE 18  
  place-and-route 18  
  simulation flows 18  
  synthesis 18  
interrupt control 7  
Interrupt Enable Register 11  
Interrupt Identification Register 11

## L

Libero Integrated Design Environment (IDE)  
  importing into 18  
  place-and-route 18  
  simulation 18  
  synthesis 18  
licenses 17  
  evaluation 17  
  Obfuscated 17  
  RTL 17  
Line Control Register 12  
Line Status Register 14

## M

Modem Control Register 13  
Modem Status Register 15

## P

parameters 19  
  top-level 19  
performance 6  
product support 31–32  
  customer service 31  
  electronic mail 31  
  technical support 31  
  telephone 32  
  website 31

## R

Receiver Buffer Register 8  
receiver synchronization 24  
register  
  read 23  
  write 23  
RWControl 7  
RXBlock 7

## S

Scratch Register 15  
simulation flows 18  
software interface 8

## T

technical support 31  
timing diagrams 23  
tool flows 17  
transmitter holding register 9  
TXBlock 8

## U

UART\_Reg 7  
user testbench 26  
utilization 6

## V

verification testbench 25  
verification tests 26

## W

web-based technical support 31







**For more information about Actel's products, visit our website at <http://www.actel.com>**

**Actel Corporation** • 2061 Stierlin Court • Mountain View, CA 94043 USA

Phone 650.318.4200 • Fax 650.318.4600 • Customer Service: 650.318.1010 • Customer Applications Center: 800.262.1060

**Actel Europe Ltd.** • River Court, Meadows Business Park • Station Approach, Blackwater • Camberley Surrey GU17 9AB • United Kingdom

Phone +44 (0) 1276 609 300 • Fax +44 (0) 1276 607 540

**Actel Japan** • EXOS Ebisu Building 4F • 1-24-14 Ebisu Shibuya-ku • Tokyo 150 • Japan

Phone +81.03.3445.7671 • Fax +81.03.3445.7668 • [www.jp.actel.com](http://www.jp.actel.com)

**Actel Hong Kong** • Room 2107, China Resources Building • 26 Harbour Road • Wanchai • Hong Kong

Phone +852 2185 6460 • Fax +852 2185 6488 • [www.actel.com.cn](http://www.actel.com.cn)

50200110-1/ 1.08

